

Stylemark Installation Instructions



1. Accurately size the panel



2. Mechanically attach the panels.



3. Double check for proper fit before you tape and finish.



4. Tape and mud to blend in with drywall



5. Paint to match the rest of the ceiling



6. Lay access panel into place



Finished Panel

 **ISC** InterSource Specialties Company

N5619 Luey Ln
Plymouth, WI 53073
920-892-8822
www.intersourceco.com
530 Cherry St.
Elmhurst, IL 60126
800-782-5011